Glassfibre and renovation fabric adhesive

Technical information sheet

500g / Item no.102619 / EAN 4016215102619

High-quality special adhesive for the secure and durable bonding of glass fibre fabric, renovation and painter's fleece as well as heavy wall coverings. Impresses with extra strong adhesive strength, very high moisture resistance and transparent drying. Easy to apply with a roller or brush and ideal for indoor use. Ensures clean results and an optimum base for subsequent work.

- for glass fibre fabric, painter's fleece, heavy wall coverings (e.g. vinyl or textile) and woodchip wallpaper
- Extra strong adhesive strength
- Very high moisture resistance when painted over
- transparent drying

Area of application

Paste for glass fibre fabric, non-woven, woodchip and heavy vinyl or textile wall coverings. For secure, permanent bonding indoors. Ideal.

Preparation

The substrate must be dry, stable, even, evenly absorbent and free of dust and grease. Remove old wallpaper and poorly adhering paint. Repair cracks, holes and unevenness with baufan interior filler. Pre-treat highly absorbent, sanding and chalking substrates and sanded surfaces with baufan Deep Penetrating Primer LF.

Processing

Mixing ratio: Pre-pasting: Mix 1:20 = 10 litres of water = approx. 70 m² Woodchip: Mix 1:11 = 5.5 litres of water = approx. 30 m² Renovation and reinforcement fleece, embossed fleece, non-woven woodchip, textile wallpaper, heavy wall coverings: Mix 1:10 = 5 litres of water = approx. 25 m² Glass fabric: Mix 1:8 = 4 litres of water = approx. 22.5 m² Sprinkle the contents of the pack quickly and rapidly into cold water while stirring vigorously and continue stirring for a short time. After approx. 15 minutes, stir the mixture again vigorously. Apply the adhesive evenly to the substrate with a short-pile roller or brush in the width of the sheet. Lay the cut-to-size sheet into the fresh adhesive bed and press down evenly and bubble-free. The processing instructions of the wallpaper or covering manufacturer must be observed. If instructed to do so by the manufacturer, apply the adhesive directly to the wall covering and bond it after the prescribed soaking time. Do not paint over the wall covering with emulsion paint until the adhesive is completely dry.

Storage

Store in a childproof, cool and dry place.

Notes

Do not process below +5 °C. Remove adhesive residues immediately with water. Clean tools with water immediately after use. Dried material residues can be disposed of with household waste or as construction site waste. EWC waste code no. 08 04 14.

Baufan Bauchemie Leipzig GmbH ■ Ludwig-Hupfeld-Straße 19 ■ 04178 Leipzig ■ Phone +49 (0)341 44655-0 ■ E-mail info@baufan.de ■ Internet www.baufan.com

Note:
All details and data presented in this information sheet are based on our practical experience and laboratory investigations, and reflect the current state of the art. They can, however, only serve as general guidance and shall provide no guarantee of specific properties or performance. Given that the conditions for storage, transportation and application of products are beyond our control, no legal liability may be construed from the information presented here. It shall be the responsibility of the user to check the product's suitability for the envisaged purpose under the specific site or project conditions.